

# MaxMountXL

## USER MANUAL



**MATRIX**air  
a division of Sol-Air

## READ AND SAVE THESE INSTRUCTIONS

For replacement Filter's and service contact 1-800-426-2611

### Warnings

1. Always unplug or disconnect the air cleaner from the power supply before servicing.
2. To reduce the risk of electric shock or injury to persons, do not expose to water or rain, and do not use in a window.

### Equipment



Each MaxMountXL unit comes with (1) 15" Bag Filter, (12) Pre-Filters, and (1) HEPA Filter.



Each unit is equipped with four (4) eye bolts and industrial hanging chain for easy installation.

### Installation

We recommend installation be performed by a licensed contractor, licensed electrician or equivalent.

#### STEP 1

After deciding on an installation location, locate the studs, rafters, or joists which the unit will be attached to. Screw eye lags to studs or rafters to match eyebolts location on unit.

#### STEP 2

Next use industrial hanging chain attach to one eyebolt. Make sure chain is tight. Next connect chain to eye lags on studs/rafters/joists. Continue this procedure for the remaining eyebolts and eye lags. Connect 120 volt power cord to power supply.

### Filter Changing\*

Pre-Filter: Replace every 3 to 4 weeks.

Bag Filter: Replace bi annually.

HEPA Filter: Replace at least every 12 months.

**\*Air Cleaner location and filter maintenance may vary according to each situation.**

#### Pre-Filter

To change the Pre-Filter unhook retainer springs the front of the cabinet. The Pre-Filter is the initial filters behind the retainer spring. Slide the front Pre-Filter out of the system and discard. Replace with new Pre-Filter.

#### Bag Filter

The Bag Filter is located directly behind the Pre-Filter. After removing the Pre Filter, slide the Bag Filter out and discard. Replace with new filter.

#### HEPA Filter

The HEPA Filter is located directly behind the Bag Filter. After removing the Pre-Filter and Bag Filter remove the 4 cleats which are held in place by (3) 10-24 screws in each cleat. After removing cleats, slide out HEPA Filter and discard. Replace with new HEPA Filter. **DO NOT WASH FILTERS**